

Read the entire instruction manual before starting so that you are familiar with the stages of assembly and the tools required at each step



TOOLS REQUIRED (Not Supplied)

- Phillips screwdriver
- Cordless drill
- Masking tape
- Tape measure
- Pencil

FOLDAWAY BIMINI TOP 2 BOW INSTRUCTIONS

COMPONENTS INCLUDED

1 Upright Bottom L	2 Upright Bottom R	3 Upright Top	4a Crossbar a	5 4x S/S Saddle	6 8x Screw	7 4x Screw
			4b Crossbar b	9 Fabric		
				10 Storage Bag		

STEP 1

Assembling Uprights

a. Release the screws from the plastic joiners.
b. Attach Upright Top (3) to the Upright Bottoms (1) and (2)
c. Align the holes and fix screws.

STEP 2

Attach Crossbars to the Fabric
Connect the Crossbars (4b) and (4a), by placing them through the loops in the fabric.

Lock pin direction

LOCK

STEP 3

Attach Uprights

a. Connect the side uprights to the 2 Crossbars (as per the picture).
b. Secure bolt (7) and nut (8) that connects the four uprights (3) to the crossbars (4a) or (4b)

STEP 4

Attach to Boat

Tighten
Release

Plug in to Oarlock Sockets

a. Plug the bimini frame into the existing oar lock sockets on the boat.
b. Prior to drilling the saddle holes into the gunnel, pull the straps down to find the most suitable position on your boat to screw down the saddle mounts.
c. Using the screws (6), secure the saddles (5) to the gunnel of the boat.
d. Attach the straps to the saddle.